

Masstabelle Jacke / size chart jacket

Bezeichnung / description:		Commander Softshell							
			XS						
	body height	Körperhöhe	156-164						
	chest	Brustumfang	78-86						
A	jacket girth 5 cm below armhole	Jackenumfang-5cm-unterhalb-Armloch	105						
E	sleevelength from neck	Aermellaenge-ab-Halsloch	73						
B	jacket length center back	Jackenlaenge-hint.-Mitte	68						
			S						
	body height	Körperhöhe	164-172						
	chest	Brustumfang	86-94						
A	jacket girth 5 cm below armhole	Jackenumfang-5cm-unterhalb-Armloch	113						
E	sleevelength from neck	Aermellaenge-ab-Halsloch	77						
B	jacket length center back	Jackenlaenge-hint.-Mitte	71						
				M	L				
	body height	Körperhöhe	172-180	172-180					
	chest	Brustumfang	94-102	102-110					
A	jacket girth 5 cm below armhole	Jackenumfang-5cm-unterhalb-Armloch	121	129					
E	sleevelength from neck	Aermellaenge-ab-Halsloch	82	84					
B	jacket length center back	Jackenlaenge-hint.-Mitte	74	74					
						XL	XXL	XXXL	XXXXL
	body height	Körperhöhe				180-188	180-188	180-188	180-188
	chest	Brustumfang				110-118	118-130	130-142	142-154
A	jacket girth 5 cm below armhole	Jackenumfang-5cm-unterhalb-Armloch				137	145	153	160
E	sleevelength from neck	Aermellaenge-ab-Halsloch				89	91	93	96
B	jacket length center back	Jackenlaenge-hint.-Mitte				77	77	77	77

